


In this guide we explain how to configure *PA* on *Klipper* using a specially crafted test object in just **one** print.


Quick and lazy (PLA-only)

Start with downloading the specially crafted [test object](#) and printing it. As the file name suggests this is meant to be printed in *PLA*.

You should end up with a hollow rectangular object. Pay close attention to the corners. You will notice that at the very bottom of the object the corners are way overextruded, causing very noticeable bulging, with the bulging gradually disappearing as the height increases. You can feel the bulging with your finger if you move it over the corner.



You will also notice that the corners start deteriorating after passing a certain height - this will be easier to see on the internal features of the test print where the groove may start blending in and almost disappearing.




Now try to find the height at which the bulge disappears but the corner is still sharp. Use a ruler to quantify this height.



In this example the optimum appears to be at 4.3mm . Now all you have to do in order to obtain the PA value is to multiply your optimal height (in millimeters) by 0.004 . For this example PA is $4.3 \cdot 0.004 = 0.172$.

Now edit your Start G-code under Filament Settings / Custom G-code in *Slic3r* and put `SET_PRESSURE_ADVANCE ADVANCE=PA` there, where `PA` is the value you have calculated.



Please note that this setting is **per filament type**.

Finally, restart *Klipper*, either by issuing `sudo service restart klipper` on the console, or by issuing `restart` in *Octoprint* terminal.

This last step is very important.

⁝ Making your own test object for any filament (advanced)

The general idea is to gradually increase the *PA* value as the print height increases.

Start with determining the parameters for *PA* probing, in other words the range of *PA* values to try out. For *PLA* you probably want to go from `0` to `0.15`. For *PET* you may want to start with `0.1` and go up to `0.2`. Please note that *PA* values above `0.2` will stress the extruder too much and are likely to cause missed steps. Now you have two parameters: `START` and `MAX`.

Decide the total height of the test object (`HEIGHT`). Too low will make it impossible to find a good *PA* value. Too high is a waste of filament and your time. We believe that `20-25mm` per `0.1` increase in *PA* is optimal.

In the configuration below we are going to use the following values (so to arrive at the same *PLA* test object as offered for download in the first section of this guide): `START=0`, `MAX=0.2`, `HEIGHT=50`.

- Get `square.stl` from *Klipper* sources (you will find it under `docs/prints`) and load it in *Slic3r*.
- Scale it vertically to `HEIGHT` (50mm).
- Add the following to the end of your `Start G-code` under `Printer Settings / Custom G-code` :

```
SET_VELOCITY_LIMIT SQUARE_CORNER_VELOCITY=1 ACCEL=500
SET_PRESSURE_ADVANCE ADVANCE_LOOKAHEAD_TIME=0
```

- Add the following to `After layer change G-code` :

```
{if layer_z > 0.4}SET_PRESSURE_ADVANCE ADVANCE={START + layer_z * ((MAX - START) /
HEIGHT)}{endif}
```

Please note that `START` and `((MAX - START) / HEIGHT)` are **numbers**. So for our *PLA* values: `{if layer_z > 0.4}SET_PRESSURE_ADVANCE ADVANCE={layer_z * 0.004}{endif}`

- Set the following slicing settings:
 - Layer height to 75% of your nozzle diameter (so 0.3mm for the most common 0.4mm nozzle).
 - 0 top solid layers.
 - 1 bottom solid layer.
 - 2 perimeters.
 - 0% infill.
 - 100mm/s printing speed (for everything save for the first layer).
- Slice and you are ready to go.

Your desired *PA* value is `START + measured_height * ((MAX - START) / HEIGHT)` , or -- using the sample `START` , `MAX` , and `HEIGHT` values -- `measured_height * 0.004` .